INSTRUCTION MANUAL
TC SERIES

Ordering Information

- ① Product
Temperature Controller
- ② Size
1 = 48H x 48W mm
2 = 96H x 48W mm
3 = 72H x 72W mm
4 = 96H x 96W mm
- ③ Method of Setting
D = Digital Switch
A = Trimmer
O = Without set

- ④ Method of Display
D = Digital LED Display
O = Without Display
- ⑤ Method of Output
R = Relay Output
V = Voltage Output
- ⑥ Method of Control
P = Proportional Control
O = ON/OFF Control

- ⑦ Alarm
A = With Stand-By/Over-Heat Alarm

- ⑧ Type of Sensor
K = K Type
Pt = Pt100Ω

⑨ Range of Setting

Digital Switch	Trimmer
W = 0 ~ 99.9	L = 0 ~ + 50
1 = 0 ~ 199	U = 0 ~ + 100
3 = 0 ~ 399	2 = 0 ~ + 200
5 = 0 ~ 599	C = 0 ~ + 300
9 = 0 ~ 999	4 = 0 ~ + 400
	F = 0 ~ + 500
	6 = 0 ~ + 600
	7 = 0 ~ + 700
	8 = 0 ~ + 800
	N = 0 ~ + 900
	A = 0 ~ + 1000
	X = 0 ~ + 1200

Specification

- ON/OFF LED
Green-Control Output Turn ON
Red-Control Output Turn Off
- AL Stand-By/Over-Heat Alarm
SV=Setting Value
AV1/AV2=Stand-By/Over-Heat
Function Selects by DIP Switch

Notice of Use

● "RESET" OFFSET

RESET Adjuster may modify the difference between present value (PV) and setted value (SV). If PV>SV may modify RESET at counterclockwise. If PV<SV may modify RESET at clockwise.

- Separate the signal line of the Sensor from power line, load line and use independent line
- Keep away from the high frequency instrument, high temperature devices or vibration machines
- Do not install the unit at the place where corrosive gasses, moisture, etc. are occurred
- Heat Load connect to NO contact, cooler Load connect to NC contact

TC1 Series 48H x 48W mm

● Dimension & Fixed Hold

● Connection Diagram

TC3 Series 72H x 72W mm

● Dimension & Fixed Hold

● Connection Diagram

TC2 Series 96H x 48W mm

● Dimension & Fixed Hold

● Connection Diagram

TC4 Series 96H x 96W mm

● Dimension & Fixed Hold

● Connection Diagram